


Required Tools

				
Screwdriver	Power Drill	Drill Bit 8 mm	Pencil	Tape Measure

Materials in the Package

				
Rail x 2	Screws x 8	Rope Cap x 12	Pulley Frame x 1	Rope x 6


How to Install



1. Hold the rail to the ceiling.
Mark screw hole positions with a pencil.


2. Drill holes at marked positions
using a Ø 8 mm drill bit.

3. Insert anchors into each drilled hole and screw each
rail firmly to the ceiling through the bracket holes.



4. Position both rails. Second rail distance = rod length (X)
minus 2 cm.
Drill and fix the second rail in the same manner.


5. Measure the rope clamp at 130–160 cm from floor.



6. Mark screw hole positions with a
pencil.

7. Drill holes for the rope
clamp in the same manner.

8. Insert anchors into each drilled
hole and screw the clamp firmly to the
wall where it was marked.



To Operate

1. Pull the rope downward — the rod lowers to a comfortable height.
2. Hang your wet laundry on the rod.
3. Pull the rope to raise the rod back up to the ceiling.
4. Secure the rope in the clamp and allow laundry to dry.

Safety Precautions

- Safety Precaution:
 - Avoid installing with:
 - Unstable ceilings
 - Electrical or water damage risks
 - Installation and Assembly:
 - This product should only be installed by a person with expertise in using power tools.
 - Make sure to use the clear instructions provided for secure installation.
 - Usage Guidelines:
 - This product is made to hang wet clothing for drying ONLY.
 - Disclaimer:
 - The product is provided on an "as is" and "as available" basis, without warranties of any kind, express or implied. In no event will Practic Home be liable for any damages or injuries resulting from:
- Misuse or neglect of the product
 - Heavy loads (wet laundry is heavier max 26lb total)
 - Failure to follow instructions or guidelines
 - Unforeseen circumstances or events
 - Any other circumstances beyond our control» Children and pets
 - By using the product, you acknowledge and agree to assume all risks and liabilities associated
 - with its use, and release Practic Home from any and all claims, demands,
 - or causes of action that may arise from any damages or injuries resulting from the foregoing.
 - Always have all six rods up when not in use.



WARNING:
CHOKING HAZARD — Small parts not for children under 3 years or any individuals who have a tendency to place inedible objects in their mouths.

THIS PRODUCT IS NOT A TOY.
 STRINGS ARE A STRANGLING HAZARD
 CHOKING HAZARD: SMALL PARTS NOT FOR CHILDREN/PETS.
 100% Satisfaction Guaranteed!
 Not satisfied with our product?
 We are here to help. Email us at info.practichome@gmail.com

Product is provided as-is without warranties of any kind. Practic Home is not liable for any damages resulting from misuse, overloading, failure to follow instructions, or unforeseen circumstances. Always keep all rods raised when not in use.